

ROLODEX[®]
BRAND

The Original Just Got Better.

Instruction Booklet for

THE ELECTRODEX PLUS™
AND
THE POCKET ELECTRODEX™



64K
MEMORY
929292

ROLODEX[®], the company known for its classic filing systems, introduces the 64K Electrodex[™] Plus and Pocket Electrodex[™], designed by leading American executives for the American way of doing business. For over 50 years Rolodex has been one of the most respected names in business and now continues that tradition with state of the art personal and business electronic organizers.

The 64K Electrodex[™] Plus and Pocket Electrodex[™] are separate products that represent a true combination of sophistication and simplicity. They feature a Business Card File to replace your paper Rolodex[®] card file, a Call List and Letters to Write List, a Reminder Note Pad, Monthly Calendar and Paper-free Calculator. They also have 2 bonus features: an Infrared Transfer System to transfer files from one unit to another through a beam of light; and, an automatic internal memory transfer, which transfers information from your Business Card File to your Call Sheet or Letters to Write list so you don't have to enter names and phone numbers twice.

Congratulations.

by **ROLODEX**[®]

The Original.

TABLE OF CONTENTS


INTRODUCTION	3
DISPLAY SCREEN	4
KEYPAD LAYOUT AND FEATURES	25-26
THE BUSINESS CARD FILE	5
How to Enter and Recall	5-11
How to Change and Erase (Erase and Replace)	12-14
How to Delete	14
How to Transfer a person's Name and Phone Number to the Call Sheet	16
How to Transfer a person's Name and Company Name to the Letters to Write list	15
THE LETTERS TO WRITE LIST	17
How to Enter and Recall	17-18
How to Delete	19
THE CALL SHEET	20
How to Enter and Recall	20-21
How to Delete	22
THE REMINDER NOTE PAD	23
How to Enter and Recall	23-24
How to Delete	27
How to Change	28-29
THE MONTHLY CALENDAR	30
THE PAPER-FREE CALCULATOR	32
CURRENCY CONVERTER	33
Programming Currency Exchange Rates	33-34
Converting Currencies	34-36
KEYTONE DN/DFF	36
PERSONAL SECURITY CODE	37-38
INFRARED TRANSFER OF FILES BETWEEN UNITS	39-44
BATTERY REPLACEMENT	45-46
MISCELLANEOUS	47-49
WARRANTY	50

INTRODUCTION

Both The Electrodex™ Plus and Pocket Electrodex™ were produced with a specific purpose in mind: to replace your old index card file. In order to gain the most efficient and maximum use out of your units, follow these suggestions:


1. Enter ALL names, phone numbers, addresses and any additional reference information into the Business Card File; this is your main database.
2. From the Business Card File use the internal transfer to send names and phone numbers to the Call Sheet, and to send names and company names to the Letters To Write list. (You should never have to enter the same name or phone number twice.)
3. Use the Call Sheet for calls to make a particular day or week, and update the list routinely (i.e., after you've made a call on the list, delete that name and number). Use the Letters To Write List the same way as the Call Sheet.
4. Use the Reminder Note Pad for all your miscellaneous notes and things-to-do.

NOTE: Both units have a complete built in "On-Screen" instruction manual. Just press **INSTR** and then or **REV FWD** to view.




DISPLAY SCREEN

SUPER TWIST LCD:



The Electrodex Plus & Pocket Electrodex both feature a 24 character across by 6 line Super-Twist display screen for your ease of viewing. This type of Super-Twist Display screen is today's state of the art. Its advantages over normal LCD displays are more clearly defined characters and viewing from multiple angles.

ON-SCREEN INDICATORS:



The Electrodex™ Plus & Pocket Electrodex™ both feature Indicators that appear on-screen at all times to signal which feature you are in.

THE BUSINESS CARD FILE

HOW TO ENTER A BUSINESS CARD FILE:




1 Press **ENTER**

2 Press **BUSINESS CARD FILE**

Type in your file following the format that appears on the display.

Example



3 To go to the beginning of the next line press **ENTER** (To skip the company name press the return key, leaving the second line blank.) If you make an error press **ERASE**

Display Reads

ALLEN MARKS-ACCOUNT EXEC DUMONT CORPORATION 232-746-5609 FAX ADDRESS CITY STATE ZIP ADDITIONAL BUSINESS INFO

4 Type in the telephone number. Use the **minus (-)** or **SPACE** key to place dashes or spaces between telephone numbers.

NOTE: The first 12 characters on the third line must be numbers. After completing the phone number simply begin the next number (fax number, home phone, extension, etc.), the unit will skip a space for you.

NOTE: If the address exceeds 24 characters the cursor will return to the next line. The rest of the file can be used for business notes, and can be as long as you like.

5. Press **BUSINESS CARD FILE** again to store the file.

Display Reads

TYPE LAST-FIRST NAME COMPANY NAME TEL NO FAX NO. ADDRESS CITY STATE ZIP ADDITIONAL BUSINESS INFO

NOTE: Also, if you press Enter, Letters to Write, Reminder Notes, Call Sheet, Monthly Calendar, or Calculator, your file will be stored.

HDW TD RECALL A BUSINESS CARD FILE (3 METHODS):

- A. RECALL BY SPECIFIC FILE NAME (PERSON'S NAME OR COMPANY NAME)**
- B. RECALL IN ALPHABETICAL ORDER**
- C. RECALL BY FAST FORWARDING THROUGH ALL FILES, A THRU Z AND D THRU 9**

A) HDW TD RECALL A SPECIFIC FILE NAME:

The ElectroDex™ Plus and Pocket ElectroDex™ have a "Cross Referencing" feature that allows you to recall the same file by the person's name OR the company name.



1 Press **BUSINESS CARD FILE**

Display Reads

TYPE IN NAME OF PERSON OR COMPANY NAME

**BCF MEMORY USED:
BCF MEMORY LEFT:**


Type in the first letter of the person's name or company name, then type in the second letter, etc. until the file appears on the display screen.

Display Reads

A

PLEASE TYPE NEXT LETTER

Example



2 Press **FURN PAGE** if the file is more

than 6 lines long. The name of the file will remain on the first line while the next 5 lines will appear from the next page.

Press **DOWN** to view the contents of the next page one line at a time.

Display Reads

ALLEN MARKS-ACCOUNT EXEC
DUMONT CORPORATION
232-555-5609 FAX 555-513B
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

IMPORTANT: If a file's contents do not appear on the screen after all the letters of the name have been entered, then there is more than one file with that name. In this case, after the full

name has been typed in, press **FWD** and all the files with that name will appear in alphabetical order.

B) HOW TO RECALL A FILE IN ALPHABETICAL ORDER:



1 Press **BUSINESS CARD FILE**

Display Reads

TYPE IN NAME OF PERSON OR COMPANY

2 Type in the first initial only of the person's name or company name.

Example

A


PLEASE TYPE NEXT LETTER

3 Press **FWD** repeatedly to

view all files with that initial.


Press **REV** to review all files

before that initial.



C) HOW TO FAST FORWARD THROUGH ALL FILES

"A" THRU "Z" AND 0 THRU 9:



1 Press **BUSINESS CARD FILE**

Display Reads

TYPE IN NAME OF PERSON OR COMPANY

2 Press and HOLD DOWN **FWD**

to fast forward through all files in alphabetical and then numerical order.

Example

30 PRINTING

MAILERS INC.

DUMONT CORPORATION

COMPUTECH

BURN ASSOCIATES

ACA COMPANY
STEVE JOHNSON
232-555-6094 FAX 555-6097
249 WASHINGTON AVE
CHICAGO IL 60601
DISCOUNT TERMS-7 PCNT.

Press **FWD** repeatedly

to view files one at a

time. Press **REV**

to review files in reverse order.

ROTARY "SPIN THE OIAL" FEATURE

HOW TO USE THE ROTARY DIAL FEATURE TO VIEW BUSINESS CARD FILES (The Electrodex Plus only):

Rotoldex® makes it easy. Rotoldex®, the company known for its filing systems, has incorporated its classic Rotary Dial into the Electrodex Plus. This unique "electronic" rotary dial allows you to spin through your Business Card Files for easy access and viewing.

1. Press **BUSINESS CARD FILE**



Display Reads
TYPE IN NAME OF PERSON
FOR COMPANY

BCF MEMORY USED:
BCF MEMORY LEFT:

2. Spin the dial to view all Business Card Files.

OR 1. Anytime **after** you have recalled a Business Card File to the display screen you may,

2. Spin the dials located on the right or left sides of The Electrodex Plus to view additional files in forward or reverse order.

NOTE: Turning the dial one click at a time will advance (or reverse) one file at a time.



HOW TO CHANGE A BUSINESS CARD FILE

(Erase and Replace):

REMEMBER: When changing files, you must erase the old information **before** you type in the new information.



- 1 Recall the file you want to change.
- 2 Press **ERASE** once. A flashing cursor appears after the last character on the first line.

Example

RECALL
ALLEN MARKS
DUMONT CORPORATION
232-746-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

BUSINESS CARDS

- 3 Use the **REV FWD** & **UP DOWN** keys to move the cursor

around the display screen. Holding down these keys will allow continuous movement of the cursor. Move the flashing cursor to the **ENO** of the word you want to delete and/or change.

4. When the character to be erased is flashing press **ERASE** until that character disappears. Now continue pressing this key to erase the complete word.

Example
ALLEN MARKS
ALLEN MARK
ALLEN MAR
ALLEN MA
OUIMONT CORPORATION
232-555-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

Example
ALLEN MARKS
OUIMONT CORPORATION
232-555-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

Example
ALLEN MARKS
OUIMONT CORPORATION
232-555-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

5. Once you have erased, you are ready to insert new information. When changing and adding information on lines 1 and 2, fit the new information within the existing 24 characters per line.

6. To update a phone number (first 12 characters) which appears on line 3, place the cursor at the beginning of the line and type in the new number. (The old number will disappear.) To update a fax number (last 11 characters), which appears on line 3, move the flashing cursor to the end of the number then erase and replace characters as described in the above points 4 and 5.

7. When changing and adding information on lines 4,5,6 and following pages, if the new information has more characters than you erased, then the existing information will automatically move to the right. If this new information exceeds the original file format of 24 characters per line, words may split and move on to the next line below.

NOTE: You can add to any line by moving the cursor to the right of the last existing character on that line and typing in the new information.

Example
ALLEN MARKS-ACCOUNT EXEC
OUIMONT CORPORATION
232-555-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

NOTE: To create and insert a new line into the middle of a file (lines 4,5,6 and following pages), move the cursor to the first character of the line you want to create and

press the  key, then move the cursor up to the blank line to enter new information.

Example-Before
ALLEN MARKS-ACCOUNT EXEC
OUIMONT CORPORATION
232-555-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

Example-After
ALLEN MARKS-ACCOUNT EXEC
OUIMONT CORPORATION
232-555-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023

NOTE: Empty lines cannot be deleted and once a tile has been changed, you cannot revert back to the original file.

HOW TO DELETE A BUSINESS CARD FILE:

1. Recall the file to be deleted.

Example
ALLEN MARKS-ACCOUNT EXEC
OUIMONT CORPORATION
232-555-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

2. Press and HOLD DOWN the

ERASE key until the tile disappears from the screen.

Display Reads
TYPE IN NAME OF PERSON
OR COMPANY

That particular file is now permanently erased from the unit's memory.

HOW TO TRANSFER A PERSON'S NAME AND COMPANY NAME FROM THE BUSINESS CARD FILE TO THE LETTERS TO WRITE LIST:



1 Recall the Business Card File you want to transfer.

Example

ALLEN MARKS-ACCOUNT EXEC
DUMONT CORPORATION
232-555-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

2 Press and HOLD DOWN **SPACE** then **LETTERS TO WRITE** once, while the space key is still down.

Display Reads

INFORMATION IS BEING PUT
INTO LETTERS TO WRITE NOW

PLEASE WAIT A MOMENT

3 The person's name and company name will be transferred instantly to the Letters To Write list in alphabetical order.

Example

ALLEN MARKS DUMONT CORP
BILL CONNER COMPUTECH
DAN HIGGINS MAILERS INC.

NOTE: In order for both the person's name and company name to appear on the same line when recalled, both names will automatically be abbreviated if necessary.

HOW TO TRANSFER A NAME AND PHONE NUMBER FROM THE BUSINESS CARD FILE TO THE CALL SHEET:



1 Recall the Business Card File you want to transfer.

Example

ALLEN MARKS-ACCOUNT EXEC
DUMONT CORPORATION
232-555-5609 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

2 Press and HOLD DOWN **SPACE** then **CALL SHEET** once, while the space key is still down.

Display Reads

INFORMATION IS BEING PUT
INTO THE CALL SHEET NOW

PLEASE WAIT A MOMENT

3 The person's name (or company name depending on which name was on line 1 of the display when you recalled the Business Card File) and phone number will be transferred instantly to the Call Sheet list in alphabetical order.

Example

ALLEN MARKS 232-555-5609
BOB WEATON 232-555-7608
DON JOHNSTON 232-555-5988

NOTE: In order for the 12-digit phone number and name to appear on the same line when recalled, the person's name or company name will be abbreviated to the first 11 characters.

THE LETTERS TO WRITE LIST

HOW TO ENTER INFORMATION (MANUALLY) INTO THE LETTERS TO WRITE LIST:



1 Press **ENTER**

2 Press **LETTERS TO WRITE**

Following the format that appears on the display, type in the name of the person you want to write.

NOTE: The cursor will return to the next line automatically after 11 characters. If the name is shorter

press then type in

the company name on the second line (12 character limit). If you make an error press **ERASE**

3. Press **LETTERS TO WRITE** to enter the file.

Display Reads

TO ENTER INFORMATION FOR
 *BUSINESS CARD FILE
 *LETTERS TO WRITE
 *REMINDER NOTES
 *THE CALL SHEET
 PRESS ABOVE CHOICE

Display Reads

TYPE IN THE PERSONS LAST
 NAME-FIRST NAME AND
 COMPANY NAME

THEN PRESS LETTERS TO
 WRITE

Example

ALLAN MARKS
 DUMONT CORP

HOW TO RECALL THE LETTERS TO WRITE LIST:



1 Press **LETTERS TO WRITE** The first 6 lines of the list will appear on the display screen.

Example

RECALL

ALLEN MARKS	DUMONT CORP
BILL CONNER	COMPUTECH
DAN HIGGINS	MAILERS INC.
FRANK SANDE	TRAVERS INC.
GREG GIBSON	BURN ASSOCIA
KARL BROWN	ACA COMPANY

LETTERS TO WRITE

RECALL

2 Press to view 6 lines at a time.

EXAMPLE

MARK JONES	JOHNSON INC.
SANDRA PAGE	CARLTON CO.
SCOTT COHEN	ADVANCED TE
STEVEN GIPPS	EAST WEST IM
TIM DRAKE	SMYTH LOANS
WARREN BUR	COUNTY PRIN


3 Press or repeatedly to view line by line through the list.

HOW TO DELETE A FILE FROM THE LETTERS TO WRITE LIST:



1 Press **LETTERS TO WRITE**

Example



2 Press **DOWN** until the line you want to delete is on the **TOP LINE** of the display.

3 Press and HOLD DOWN **ERASE** until the file (top line only) disappears. Remaining files will move up automatically.

THE CALL SHEET HOW TO ENTER INFORMATION (MANUALLY) INTO THE CALL SHEET:



1 Press **ENTER**

TO ENTER INFORMATION FOR
• BUSINESS CARD FILE
• LETTERS TO WRITE
• REMINDER NOTES
• THE CALL SHEET
PRESS THE ABOVE CHOICE

2 Press **CALL SHEET**

Type in the first 11 characters of the person's last name only.

NOTE: The cursor will return to the next line automatically after 11 characters. If the name is shorter

press **UP** then type in

the telephone number on the second line (12 character limit, numerals only). If you make an error press **ERASE**

3. Press **CALL SHEET** to enter the file.

Display Reads
TYPE IN THE PERSONS LAST
NAME AND
TEL. NO

THEN PRESS CALL SHEET

Example

ALAN MARKS-ACCOUNT EXEC
DUMONT CORPORATION
232-555-5609 FAX-555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10002
1990 SALES VOLUME 745000

HOW TO RECALL THE CALL SHEET:



1 Press **CALL SHEET** The first 6 lines of the list will appear on the display screen.

Example



2 Press **TURN PAGE** to view 6 lines at a time.

3 Press **UP** or **DOWN** repeatedly to view line by line through the list.

HOW TO DELETE A FILE FROM THE CALL SHEET:



1 Press **CALL SHEET**

Example



2 Press **DOWN** until the line you want to delete is on the **TOP LINE** of the display.

3 Press and **HOLD DOWN** **ERASE** until the file (top line only) disappears. Remaining files will move up automatically.

THE REMINDER NOTE PAD

HOW TO ENTER A REMINDER NOTE FILE:



1 Press **ENTER**

2 Press **REMINDER NOTES**

3. Type in your Reminder Note information. If you make an error press **ERASE**

NOTE: Each Reminder Note file will automatically indent after the first line when recalled for easy viewing (see "Example-After"). While entering information leave the last character of each line blank. Press the return key before reaching the end of the line to allow for an indentation and avoid breaking up words upon recall.

Display Reads

TO ENTER INFORMATION FOR
 'BUSINESS CARD FILE'
 'LETTERS TO WRITE'
 'REMINDER NOTES'
 'THE CALL SHEET'
 PRESS ABOVE CHOICE

Display Reads

TYPE IN ANOTHER REMINDER
 NOTE IF YOU WANT AND A
 DATE IF IT APPLIES
 THEN PRESS REMINDER NOTE

Example-Before

File 1
 12-7-90 C.D. MATURES
 ROLL OVER FOR 60 DAYS
 FAX ACCOUNT LIST TO TED
 File 2
 BEFORE SALES MEETING
 SET UP MEETING WITH JOHN
 REGARDING ADVERTISING

Example-After

File 1
 12-7-90 C.D. MATURES
 ROLL OVER FOR 60 DAYS
 FAX ACCOUNT LIST TO TED
 File 2
 BEFORE SALES MEETING
 SET UP MEETING WITH JOHN
 REGARDING ADVERTISING

NOTE: If you enter a date at the beginning of a file, place a zero (0) before all single digit months and days. This way they will appear in chronological order when recalled.

Example


02-07-90 C.D. MATURES
 ROLL OVER FOR 60 DAYS
 05-02-90 DAVID WEATON
 DINNER AT 6PM
 11-09-90 DUMONT CORP
 PRODUCTION DATES DUE

HOW TO RECALL THE REMINDER NOTE PAD:




1 Press **REMINDER NOTES** The first 6 lines of the list will appear on the display screen.

Example



2 Press **UP** to view 6 lines at a time. Press **DOWN** repeatedly to view line by line through the list.

KEYPAD LAYOUT AND FEATURES




HOW TO OELTE A FILE FROM THE REMINOER NOTE PAO:



1 Press

REMINOER
NOTES

Example



2 Press until the file you want to delete is on the TOP LINE of the display.

3 Press and HDLD DOWN until the file (top line and indented lines which follow) disappears. Remaining files will move up automatically.

NOTE: Do not erase character by character to delete a Reminder Note File. This will leave a blank file that will show blank display lines when you recall your Reminder Notes.


HOW TO CHANGE A FILE IN THE REMINOER NOTE PAO:



1 Press

REMINOER
NOTES

Example



2 Press until the file you want to change is on the TOP LINE of the display.

3 Press and the cursor will appear to the right of the last character on that line (all other entries will disappear from the screen but will not have been erased).

Example-Before

FAX ACCOUNT LIST TO TEO
BEFORE SALES MEETING
SET UP MEETING WITH JOHN
REGAROING AOVERTISING

Example-After

FAX ACCOUNT LIST TO TEO
BEFORE SALES MEETING

4. When the character to be erased is flashing press **ERASE** until that character disappears. Now continue pressing this key to erase the complete word.

5. Once you have finished erasing, you are ready to insert new information. If the new information has more characters than you erased, then the existing information will automatically move to the right. If this new information exceeds the original file format of 24 characters per line, words may split and move on to the next line below.

NOTE: To create and insert a new line into the middle of a file, move the cursor to the first character of the line you want to create and

press the **▲** key, then move the

cursor up to the blank line to enter new information.

NOTE: You can add to any line by moving the cursor to the right of the last existing character on that line and typing in the new information.

NOTE: Empty lines cannot be deleted and once a file has been changed, you cannot revert back to the original file.

Example

FAX ACCOUNT LIST TO TEO
FAX ACCOUNT LIST TO TE
FAX ACCOUNT LIST TO T
FAX ACCOUNT LIST TO
BEFORE SALES MEETING
FAX ACCOUNT LIST LISA
BEFORE SALES MEETING

Example-Before

FAX ACCOUNT LIST LISA
BEFORE SALES MEETING

Example-Before

FAX ACCOUNT LIST LISA
BEFORE SALES MEETING

Example

FAX ACCOUNT LIST LISA
JONES ON APRIL 20
BEFORE SALES MEETING

THE MONTHLY CALENDAR

HOW TO USE THE MONTHLY CALENDAR:



1 Press

CALENDAR

Example

SUN	MON	TUE	WED	THU	FRI	SAT
1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30					

SEP 1991

2

REV

FWD

to reverse or advance through the months. Hold down these keys to fast forward or fast reverse.

3

UP

DOWN

to reverse or advance through the years. Hold down these keys to fast forward, or fast reverse.

THE PAPER-FREE CALCULATOR

HOW TO USE THE PAPER-FREE CALCULATOR:



Display Reads

1 Press **CALCULATOR**

2. Enter your calculation.

NOTE: To clear last entry press **CALCULATOR**. To clear all calculations press **CALCULATOR** twice.

NOTE: The calculator will automatically subtotal your calculations as your entry exceeds the 6 lines on the display screen. Line 1 of the second page will show the previous page's subtotal.

Example

X	12573.95
-	5
+	6329.00
+	56.00
+	167.00
÷	7

Example

=	8109.1071
=	

CURRENCY CONVERTER

HOW TO PROGRAM CURRENCY EXCHANGE RATES:



1 Press **CALCULATOR**

2 Press the letter "X". Display Reads



3 Using move the flashing cursor next to the country currency abbreviation.

4. Type in the exchange rate which equals one U.S. Dollar.

NOTE: The U.S. Dollar is preset to 1.

CAND 1.2	DM 0.73	NT
E.PD	PESO	
FF	SF	
HKD	USD 1	
LTRA	YEN	


5. You can enter 9 more country exchange rates by moving the cursor.

6. Press the letter "X" again to confirm entries.

NOTE: For currencies with an exchange rate less than 1 you must type in a zero before the decimal point (e.g. 0.53)

HOW TO CONVERT CURRENCIES:

Example #1: Let's say that \$1 U.S. Dollar is worth £.53 English Pounds. How many U.S. Dollars could you buy with £200 English Pounds?



1 Press **CALCULATOR**

2 Press the letter "X".

3. Without moving the cursor, type in "200".

Example 200

CAND	DM	NT
DM	200.00	PESO
E.PD	200.00	SF
FF	SF	
HKD	USD 377.35	
LTRA	YEN	

4 Press the alphabet key which is the first initial of the foreign currency you've entered. (C,D,E,F, H,L,N,P,S,U,Y). In this example press "E" for E.PD (English Pound)

Example

CAND	DM	NT
DM	200.00	PESO
E.PD	200.00	SF
FF	SF	
HKD	USD 377.35	
LTRA	YEN	

5. Then "\$377.35" will appear next to USD.

In other words £20D English Pounds is worth \$377.35 U.S Dollars. The correct amount will also appear next to other currencies you've entered an exchange rate for.

Example #2: You have \$50 U.S. Dollars and you want to find out what they are worth in English Pounds. Display Pounds

1. Press **CALCULATOR**

2. Press the letter "X".

3. Type in "5D".

4. Press the letter "U" which stands for U.S. Dollars.

5. Then "26.5DD" will appear next to E. PD. showing that \$5D U.S. will only bring £26.5. All other currencies you've programmed will display how much \$5D U.S. are worth in their currencies also.

HOW TO UPDATE CURRENCY EXCHANGE RATES:

1 Press **CALCULATOR**

2 Press the letter **X**.

3. Move the cursor to the desired currency.

4. Simply press **ERASE** to erase the old rate and type in the new rate.

5. Press the letter "X" to confirm.

35

Display Reeds
CAND
DM NT
E.PD 26.500 PESO
FF SF
HKO USD 50.000
LTRA YEN

Display Reads

CAND	
DM	NT
E,PD	26.590 PESD
FF	SF
HKD	USD 50.000
LTRA	YEN

Display Reads

CAND		
DM	NT	
E.PD	26.500	PESO
FF	SF	
HKD	USD	50.000
LTRA	YEN	

Example	
CAND	
DM	NT
E.PD	0.63
FF	SF
HKD	USD
LTRA	1
	YEN

CURRENCY CONVERSION ABBREVIATIONS:

The currency converter lets you store up to 11 foreign exchange rates. The Country/Currency abbreviations are:

CAND:	Canadian Dollar
DM:	Deutschmark
E. PD:	English Pound
FF:	French Franc
HKD:	Hong Kong Dollar
LTRA:	Italian Lira
NT:	New Taiwan Yuan
PESD:	Mexican Peso
SF:	Swiss Franc
USD:	U.S. Dollar
YEN:	Japanese Yen

KEYTONE ON/OFF

HOW TO TURN THE KEYTONE ON OR OFF:



1 Press and HOLD DOWN **SPACE** then press the letter **K** while the space key is still down.

PERSONAL SECURITY CODE

HOW TO ENTER YOUR PERSONAL SECURITY CODE:



- 1 Press and HOLD DOWN **SPACE** then press  once, while the space key is still down.

2. Type in any 2 digits of your choosing. **NOTE:** Do not forget your security code number. Write it down on paper and store in a safe place.

- 3 Press  to confirm. Your code will remain in memory until you choose to remove it.

Display Reads
TYPE IN ANY 2 NUMBERS
FOR YOUR CODE
—
THEN PRESS ENTER

Example
TYPE IN ANY 2 NUMBERS
FOR YOUR CODE
65
THEN PRESS ENTER

Example
YOUR SECURITY CODE IS
NOW STORED IN THE
MEMORY

HOW TO LOCK YOUR UNIT:

In order to lock your unit you must have already entered your 2-digit code.



- 1 Press and HOLD DOWN **SPACE** then press  once, while the space key is still down. The unit is now locked.

Display Reads
THE SECURITY CODE IS NOW
ON

HOW TO UNLOCK YOUR UNIT AND GAIN ACCESS TO YOUR FILES:

1. Press the feature key you want to recall (i.e. Business Card File).
2. Type in your 2-digit code.
3. Recall your files.

Display Reads
TYPE IN YOUR SECURITY
CODE—

HOW TO REMOVE YOUR CODE FROM THE CODE MEMORY:

1. When the display reads "TYPE IN YOUR SECURITY CODE—", press and HOLD DOWN  then type in your 2-digit code, while the Erase key is still down.
2. The removal of your code from memory will be confirmed on the display screen.

Display Reads
YOUR SECURITY CODE HAS
BEEN DELETED

INFRARED TRANSFER SYSTEM

The Electrodex™ Plus & Pocket Electrodex™ have a revolutionary Infrared (wireless) Transfer System which allows you to transfer Business Cards from either unit to the other.

There are 4 options available between The Electrodex™ Plus and The Pocket Electrodex™ to update and exchange files:



*Transfer from
one Pocket Electrodex™ to another.*



*Transfer from an Electrodex™ Plus
to another.*

*Transfer from a Pocket Electrodex™
to an Electrodex™ Plus.*



*Transfer from an Electrodex™ Plus
to a Pocket Electrodex™.*



NOTE: The receiving unit must be placed on the left and the sending unit must be placed on the right.

HOW TO TRANSFER "ALL" FILES

RECEIVING UNIT ON THE LEFT (INCOMING):



- 1 To make the receiving unit ready, turn on the receiving unit first by pressing **BUSINESS CARD FILE**

Display Reads

TYPE IN NAME OF PERSON
OR COMPANY NAME

BCF MEMORY USED:
BCF MEMORY LEFT:

- 2 Press and HOLD DOWN

SPACE

and press **R**

(for "receive") once, while the space key is still down.

3. Now prepare the sending unit. After your transfer, the receiving unit will take a few moments to sort the information transferred.

NOTE: Before doing an "ALL" file transfer, check the memory available status of the receiving unit. Compare the memory used status on the sending unit to calculate whether enough memory will be available to complete the transfer.

OR ALL "NEW" FILES ONLY:

SENDING UNIT ON THE RIGHT (OUTGOING):



- 1 To make the sending unit ready, turn on the sending unit first by pressing **BUSINESS CARD FILE**

Display Reads

TYPE IN NAME OF PERSON
OR COMPANY NAME

BCF MEMORY USED:
BCF MEMORY LEFT:

Display Reads

INFORMATION IS BEING
RECEIVED

PLEASE WAIT A MOMENT

Display Reads

INFORMATION IS BEING
SORTED

PLEASE WAIT A MOMENT

Display Reads

TYPE IN ALL TO
TRANSMIT ALL THE FILES
OR
TYPE IN NEW TO
TRANSMIT NEW FILES ONLY

- 2 Press and HOLD DOWN

SPACE



(for "load") once, while the space key is still down.

3. Type in "ALL" to send all files, or type in "NEW" to send only the files entered since the last transfer.

NOTE: When the transfer is completed (several seconds) the most recent file that you entered into the sending unit will appear on both display screens. This confirms that the transfer has been successfully completed.

IMPORTANT: Avoid transferring ALL files to a unit which already contains those files. Those files will be duplicated in the receiving unit.

HOW TO TRANSFER ONLY "ONE" BUSINESS CARD FILE:

RECEIVING UNIT ON THE LEFT (INCOMING):



Display Reads

TYPE IN NAME OF PERSON
OR COMPANY NAME

BCF MEMORY USED:
BCF MEMORY LEFT:

1 To make the receiving unit ready, turn on the receiving unit **first** by pressing **BUSINESS CARD FILE**

SENDING UNIT ON THE RIGHT (OUTGOING):



Example

ALLEN MARKS-ACCOUNT EXEC
DUMONT CORPORATION
232-555-5690 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

1 Recall the individual Business Card File you want to transfer. When the file appears on the display screen place the unit to the right of the receiving unit, almost touching.

2 Press and **HOLD DOWN** **SPACE** and press **R** (for "receive") once, **while the space key is still down**.

3. Now prepare sending unit.

NOTE: After your transfer, the receiving unit will show the file that has just been transferred.

Display Reads

INFORMATION IS BEING RECEIVED

PLEASE WAIT A MOMENT



Display Reads

INFORMATION IS BEING TRANSFERRED

PLEASE WAIT A MOMENT

2 Press and **HOLD DOWN** **SPACE** and press **L** (for "load") once, **while the space key is still down**.

NOTE: When the file reappears on the receiving unit's screen (almost instantly), the transfer has been successfully completed.

Example

ALLEN MARKS-ACCOUNT EXEC
DUMONT CORPORATION
232-555-5690 FAX 555-5138
888 PARK AVENUE SUITE 7
NEW YORK NEW YORK 10023
1990 SALES VOLUME 745000

BATTERY REPLACEMENT

HOW TO REPLACE THE POCKET ELECTROOEX™ BATTERIES:


If your display screen starts to lose its contrast, it is time to replace the primary batteries. Your primary batteries should last approximately 2 years, based on an average use of 1 hour per day (20 times per day, 3 minutes each time). The battery life may vary according to your usage. The back-up battery saves your unit's memory while the primary batteries are being replaced. The back-up battery should be replaced every 3 years.

The Pocket Electrodex™ battery rating:

Primary Batteries™ (2): CR2430

Back-Up Battery (1): CR2016

NOTE: If all 3 batteries are removed at one time, the memory will be erased.



To replace the batteries remove the back cover of the unit. Use a screwdriver to remove the clip fastening screws. Locate the primary batteries as shown above.

Replace with new batteries from the specifications given above. If you can't find the correct batteries call our "HELP" numbers as listed on the warranty.

HOW TO REPLACE THE ELECTROOEX™ PLUS BATTERIES:


If your display screen starts to lose its contrast, it is time to replace the primary batteries. Your primary batteries should last approximately 2 years, based on an average use of 1 hour per day (20 times per day, 3 minutes each time). The Electrodex™ Plus contains a lithium no-loss memory back-up battery which holds the memory while the 4 primary batteries are being replaced. The back-up battery is concealed within the unit and should not require replacement.

The Electrodex™ Plus battery rating:

Primary Batteries (4): AA Alkaline Batteries

Back-Up Battery (1): CR2430 Lithium

To replace the batteries remove the battery plate on the bottom of the Electrodex™ Plus and replace the 4 AA batteries arranging them as shown:



An AC/DC adaptor may also be used with The Electrodex™ Plus and can be purchased from an electronics store.

Reminder

When using AC Adapter, Model No. 223-1650 Archer, the voltage must be set to match unit specifications.
I.e.: 4.5 V or 6 V

The yellow tipped adapter plug is the only plug that will make the unit function. The word "TIP" on the yellow plug should always plug into the "—NEC" label on the cord connector.



MISCELLANEOUS

THE BUSINESS CARD FILE SORTING ORDER:

All Business Card Files are automatically sorted in alphabetical and then numerical order. This applies to both individual's names and company names that cross-reference each other.

NOTE: When recalling a name that exceeds 8 characters, if there is more than one file with the same name press  to bring the files



up on the display screen.

NOTE: The automatic sorting applies to the first 8 characters on line 1 and 2 of a Business Card File. When there is more than one file with the same name and that name exceeds 8 characters, these files will be recalled in the same order that they were originally entered.

NOTE: As you press  to view additional pages of a

Business Card File; the file name (from Line 1 of the first page will remain on Line 1 as a reminder of which file you are viewing.

NOTE: The Business Card File display format suggests that you enter a person's last name and then first name. This is suggested since first names are more common and the duplication of many of the same first names will slow down the direct search procedure when recalling the file. Please note however that it is not mandatory to use last names first.



MEMORY SPACE AVAILABILITY:

There are 10 display pages of space available for each of the following:

LETTERS
TO WRITE

REMINDER
NOTES

CALL
SHEET

Display Reads

TYPE IN NAME OF PERSON OR
COMPANY NAME

BCF MEMORY USED: 22341
BCF MEMORY LEFT: 41569

NOTE: The Business Card File occupies the majority of the 64K (64,000 character) memory. Every time you recall a Business Card File the display will show you how much memory you have used and how much you still have left. Individual Business Card Files can hold up to 10 display pages.

INFRARED TRANSFER SYSTEM:

IMPORTANT: If you intend to transfer Business Card files back and forth between units you must note that the files most recently transferred into the receiving unit will continue to register as "new" files when transferred back to the original sending unit. In order to avoid unnecessary duplication of files between units we recommend the following procedure:



1. Transfer ALL or all NEW files from one unit to the other.



2. Transfer all NEW files from the receiving unit into the air so that these files will not be considered NEW in future transfers.



3. Now when you transfer files back to the original sending unit, you will not duplicate files from the previous transfer.

NOTE: This example applies to all 4 transferring options.

MEMORY RESET:

To INTENTIONALLY delete ALL file information (clear the file memory entirely).

1. Press and HOLD DOWN **ENTER**

2. Locate the RESET hole on the back of the unit and insert the tip of a paper clip, **while the Enter key is still down.**

3. Watch the display screen change to a full dot display.

4. Release the **ENTER** key.

5. Insert the tip of the paper clip again, the display will return to normal and all files will have been deleted.

NOTE: If at any time information on the display screen should freeze and the keypad does not work properly, simply press in the RESET button. The display screen will unfreeze and your files will remain intact in the memory. (**Do not press Enter.**)

BACK-UP INFORMATION:

As with all computers, it is advisable to keep a written copy of all information stored in your ElectroDex™ Plus or Pocket ElectroDex™ in case it is lost, stolen, or physically damaged.

WARNING:

It is advisable to avoid X-Ray and magnetic fields, such as airport security systems. This can cause scrambling or loss of unit's memory.

AUTOMATIC SHUT-OFF:

Your unit will shut off automatically after 3 minutes of non-use.

LIMITED WARRANTY

Tele-Art, Ltd. warrants to the original purchaser of this product, that if this product proves to be defective in material or workmanship, we will repair or replace it without charge for a period of 1 year from the date of original purchase.

This limited warranty covers repair or replacement without charge, only when defective product is submitted to Tele-Art, Ltd. with proof of original purchase.

This limited warranty covers all defects incurred in normal use. It does not apply to any unit that has been subject to alteration, modification, abuse, negligence, accident or use in any manner contrary to instructions herein by Tele-Art, Ltd.

Tele-Art, Ltd.'s liability is limited solely to the repair of this product. We disclaim liability for consequential damages, for breach of any express or implied warranties including merchantability or fitness for purpose. This warranty gives you specific legal rights and you may have other rights that may vary from state to state.

To receive service or a replacement product under this warranty, contact the ROLODEX Electronics Service Center directly. Send (postage insured for your own protection) the defective product along with proof of purchase and \$10.00 to cover return handling, packing, insurance & postage to:

ROLODEX ELECTRONICS SERVICE CENTER
245 Secaucus Road • Secaucus, NJ 07094-2196

If you have any questions about this product call the HELP LINE
1-800-727-ROLO (7656)

© TM TELE-ART 1990

Rolodex ® is a registered trademark of
 Rolodex Corporation

Lic. U.S. Pat. 4,117,542
PRINTEO IN HONG KONG